



User Manual

Open Vertical Electric MCH22-36

Rev. 03.20



If you have any questions on this equipment please contact Technical Support at:

Nuvair
1600 Beacon Place
Oxnard, CA 93033

Phone: +1 805 815 4044

Fax: +1 805 486 0900

Email: info@Nuvair.com

Hours: Monday through Friday
8:00 AM to 5:00 PM PST USA

Warning

This User Manual contains important safety information and should always be available to those personnel operating this equipment. Read, understand, and retain all instructions before operating this equipment to prevent injury or equipment damage.

Every effort was made to ensure the accuracy of the information contained within. Nuvair, however, retains the right to modify its contents without notice.

Under Nuvair's system of continuous improvement, certain components may be updated or changed as higher quality or more efficient parts and assemblies become available.

Nuvair will make every effort to update manuals as parts and functional aspects change. However, the look or location of components on your product may differ from those in this manual if improvements have been made that do not affect functionality or operational procedures.

Units pictured may also be equipped with different options than those on your product. In this case, the basic operational and maintenance guidelines will still apply.

If you have problems or questions after reading the manual, stop and call Nuvair at +1 805 815 4044 for information.

Table of Contents

Introduction

1.0	Introduction.....	4
1.1	Required Operator Training.....	4
1.2	Important Information for the User.....	4
1.3	Foreword.....	5
1.4	Assistance	5
1.5	Responsibility.....	5
1.6	Purpose of the Machine.....	6
1.7	Where the Compressor may be used.....	8
1.8	Running and Testing the Compressor.....	8
2.0	Safety Warnings.....	9
3.0	Safety and Operation Precautions.....	10
4.0	General Description of the Compressor.....	11
5.0	System Components.....	12
6.0	Compressor Specifications	13
6.1	Unpack and Installation.....	13
6.2	Electrical Connection	14
7.0	Checks to be run at the start of each working day	14
7.1	Lubricating oil check	14
7.2	Check the refill hoses are in good condition	14
7.3	Storing technical documentation.....	14
8.0	Gauge Panel.....	15
9.0	Overpressure Safety Valves	15
10.0	Bottle Refill	16
11.0	Maintenance	16
11.1	Forward.....	16
11.2	General.....	17
11.3	Unscheduled Work.....	17
11.4	Scheduled Maintenance Table	17
11.5	Troubleshooting	18
11.6	Checking and Changing the Lubricating Oil and Filter	18
11.7	Checking the Oil Level.....	19
11.8	Changing the Lubricating Oil and Filter	20
11.9	Tightening Torque Value	21
11.11	Changing the Air Intake Filter	21
12.0	Transmission Belt	22
12.1	Checking the Transmission Belt	22
13.0	HP Compressor Filtration Active Carbon Filters / Molecular Sieve	23
13.1	Temperature effect on filter life	24
13.2	Condensate Discharge	24
14.0	Power Requirements	25

Table of Contents

14.1	Amperage Load for the System.....	25
14.2	Rotation Check.....	25
15.0	Storage.....	26
15.1	Stopping the Machine for a Brief Period.....	26
15.2	Stopping the Machine for a Long Period.....	26
16.0	Dismantling and Putting the Compressor Out of Service.....	26
16.1	Waste Disposal.....	26
16.2	Dismantling the Compressor.....	27
17.0	Instructions for Emergency Situations.....	27
17.1	Fire.....	27
18.0	Maintenance Register.....	27
18.1	Customer Service.....	27
18.2	Scheduled Maintenance.....	27
18.3	Using the Compressor Under Heavy Duty Conditions.....	27
18.4	Nuvair Customer Care Contact.....	28
19.0	Spare Parts List.....	28
20.0	Service Record Log.....	29
21.0	Appendix.....	31
	Supply and Breathing Air Specifications	
	Nuvair System Compressor Warranty Info	
	Additional Record of Changes	
	Notes	

Separate Manuals Included:

Compressor Parts Manual

1.0 Introduction

This manual will assist you in the proper set-up, operation and maintenance of the Nuvair Open Electric compressor packages. Be sure to read the entire manual. Throughout this manual we will use certain words to call your attention to conditions, practices or techniques that may directly affect your safety. Pay particular attention to information introduced by the following signal words:

Danger

Indicates an imminently hazardous situation which, if not avoided, will result in serious injury or death.

Warning

Indicates a potentially hazardous situation which, if not avoided, could result in serious personal injury or death.

Caution

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

Notice

Notifies people of installation, operation or maintenance information which is important but not hazard-related.

1.1 Required Operator Training

This manual must be read carefully and entirely

- All compressor operators / maintenance personnel must read this entire manual with due care and attention and observe the instructions/information contained herein.
- Company owners ensure that the operator has the required training for operation of the compressor and that he/she has read the manual.

1.2 Important Information for the User

The information/instructions for compressor use contained in this manual concern the **Nuvair** compressors: **Open Vertical Electric**

The instruction manual must be read and used as follows:

- Read this manual carefully; treat it as an essential part of the compressor
- The instruction manual must be kept where it can readily be consulted by compressor operators and maintenance staff
- Keep the manual for the working life of the compressor
- Make sure updates are incorporated in the manual
- Make sure the manual is given to other users or subsequent owners in the event of resale
- Keep the manual in good condition and ensure its contents remain undamaged
- Do not remove, tear or re-write any part of the manual for any reason
- Keep the manual protected from damp and heat
- If the manual is lost or partially damaged and its contents cannot be read it is advisable to request a copy from the manufacturer

1.3 Foreword

The regulations/instructions for use contained in this manual constitute an essential component of the supplied compressor.

These regulations/instructions are intended for an operator who has already been trained to use this type of compressor. The contained information is necessary and essential to efficient and proper use of the compressor.

Hurried or careless preparation leads to improvisation, which is the cause of accidents.

Before beginning work, read the following suggestions carefully:

- 1) Before using the compressor, gain familiarity with the tasks to be completed and the admissible working position
- 2) The operator must always have the instruction manual to hand
- 3) Plan all work with due care and attention
- 4) You must have a detailed understanding of where and how the compressor is to be used
- 5) Before starting work make sure that safety devices are working properly and that their use is understood; in the event of any doubts do not use the compressor
- 6) Observe the warnings given in this manual with due care and attention
- 7) Constant and careful preventive maintenance will always ensure a high level of safety when using the compressor. Never postpone repairs and have them carried out by specialized personnel only; use only original spare parts

1.4 Assistance

Nuvair technicians are at your disposal for all routine/unscheduled maintenance work. Please forward your request for assistance to **Nuvair** by sending a fax or e-mail to:

Phone: +1 805 815 4044
Fax: +1 805 486 0900
Email: info@Nuvair.com

1.5 Responsibility

Nuvair considers itself exonerated from any responsibility or obligation regarding injury or damage caused by:

- Failure to observe the instructions contained in this manual that concern the running, use and maintenance of the compressor
- Violent actions or incorrect maneuvers during use or maintenance of the compressor
- Modifications made to the compressor without prior written authorization from **Nuvair**
- Incidents beyond the scope of routine, proper use of the compressor

Warning

Maintenance and repairs must only be carried out using original spare parts and qualified technicians. Nuvair cannot be held liable for any damages caused by failure to observe this rule. The compressor is guaranteed as per the contractual agreements made at the time of sale. Failure to observe the regulations and instructions for use contained in this manual shall render the warranty null and void.

1.6 Purpose of the Machine

This high pressure compressor has been designed and built for the purpose of producing breathing air by drawing it from the surrounding environment. The surrounding environment air must be free from any harmful fumes or contaminants. The air is pulled through an intake air filter, compressed, and passed through breathing air filtration before it is stored in bottles constructed to contain air at high pressure. The compressor can also be used for the pumping of gases:

- Nitrogen
- Helium
- Nitrox mixtures up to 40%

Any other use is inappropriate. The manufacturer cannot be held liable for any personal injury or damage to objects / the machine itself caused by improper use.

Danger

- **Use only tested, certified bottles: do not exceed the working pressure indicated on them.**
- **Drain air from tanks before filling when tanks have not been used for an extended period of time.**
- **Use the compressor in areas free from dust, risk of explosion, corrosion and fire.**
- **Improper use could have serious consequences for the user.**
- **Do not disconnect the hose from the fittings or the clamp when under pressure.**
- **Change the air purification filters regularly as described in section 13.0.**
- **Drain the condensate regularly as illustrated in section 13.2: Condensate Discharge.**
- **The power must be disconnected and locked out before carrying out any cleaning or maintenance tasks.**
- **Never pull a plug out by tugging the cord. Make sure the cord is not bent at a sharp angle and that it does not rub against any sharp edges. Use of extensions is not advised.**
- **Never operate the compressor when the power cord is damaged**
- **All routine and unscheduled maintenance tasks must be carried out with the compressor at a standstill, the electrical power supply disconnected or locked out and all lines are depressurized.**
- **After switching off the compressor wait about 30 minutes before carrying out any maintenance tasks so as to prevent burns.**
- **The high pressure flex hose (also called the fill whip) that connects the compressor to the bottle must be in good condition, especially in the areas near the fittings. The plastic sheath that covers the hose must not show any signs of abrasion, otherwise moisture could get in and corrode the steel braid thus weakening it. The hose must be changed periodically (yearly) or when it shows signs of wear. Failure to observe this rule could seriously endanger the users' safety. Make sure the minimum bending radius of the hose is no less than 10 inches (250 mm).**

Nuvair MCH36 Open Vertical

To ensure maximum working efficiency, **Nuvair** has constructed the compressor with carefully selected components and materials. The compressor is tested prior to delivery. Continued compressor efficiency over time will also depend on proper use and maintenance as per the instructions contained in this manual.

All the components, connections and controls used in its construction have been designed and built to a high degree of safety so as to resist abnormal strain or in any case a strain greater than that indicated in the manual. Materials are of the finest quality; their introduction and storage in the company and their utilization in the workshop are controlled constantly so as to prevent any damage, deterioration or malfunction.

Danger

Before carrying out any work on the compressor each operator must have a perfect understanding of how the compressor works, know how to use the controls and have read the technical information contained in this manual.

- **It is forbidden to use the compressor under conditions or for purposes other than those indicated in this manual and Nuvair cannot be held liable for breakdowns, problems or accidents caused by failure to observe this rule.**
- **Check that the fittings provide a proper seal by wetting them with soapy water: Stop the compressor and eliminate any leaks immediately when detected.**
- **Do not attempt to repair high pressure tubes by welding them or while the compressor is running.**
- **Do not empty the bottles completely, not even during winter storage as this practice allows damp air to get in and eventually corrode the bottle.**
- **It is forbidden to tamper with, alter or modify, even partially, the systems and equipment described in this instruction manual, especially as safety guards and safety symbols are concerned.**
- **It is also forbidden to carry out work in any way other than that described or to neglect the illustrated safety tasks.**
- **The safety information and the general information given in this manual are highly important.**

1.7 Where the Compressor may be used

This high pressure compressor has been designed and built for the purpose of producing breathing air by drawing it from the surrounding environment. The surrounding environment air must be free from any harmful fumes or contaminates. The air is passed through an intake air filter, compressed and run through breathing air filtration before it is stored in bottles constructed to contain air at high pressure. The compressor must only be used in environments having the characteristics described in the following table.

Area of Machine Use: Essential Data Table		
Temperature ambient		Min. +41°F - Max. +113°F (Min. +5°C - Max. +45°C)
Air humidity	(%)	Maximum 80%
Tolerated Weather Conditions	rain	none
	hail	
	snow	
Max tilt angle (bank)	(%)	6%

Check that the area in which the compressor is to be positioned is adequately ventilated: good air exchange (more than one window) with no dust and no risk of explosion, corrosion or fire. If ambient temperatures exceed 113°F (45°C) air conditioning will be required. Make sure that lighting in the area is sufficient to identify every detail (such as the writing on the info plates/stickers); use artificial lighting where daylight on its own is insufficient.

- When Pumping Nitrox, Ambient temperature Maximum is 100°F and Maximum fill pressure is 3600 psi.

1.8 Running and Testing the Compressor

Each compressor is carefully ran and tested prior to delivery. A new compressor must nevertheless be used with caution during the first 5 working hours so as to complete proper breaking in of its components. If the compressor is subject to an excessive workload during initial use, its potential efficiency will be prematurely compromised and functionality soon reduced. During the breaking in period proceed as follows:

- After starting the unit, let the compressor run un-loaded for 5-6 minutes.

After the first 25 hours carry out in addition to the scheduled maintenance the following tasks:

- Change the compressor oil
- Change the oil filter
- Check and adjust nuts and bolts

 **Warning**

When changing the oil filter, inspect the filter element and check for any deposits. If metal or carbon deposits are present, locate the source before restarting the compressor.

2.0 Safety Warnings

Nuvair has taken extreme care in providing you with the information you will need to operate this system. However, it is up to you to carefully read this manual and make the appropriate decisions about system safety.

Warning

This equipment is used to provide breathing Air or Nitrox for the purpose of life support. Read this manual in its entirety. Failure to heed the warnings and cautions contained in this document may result in severe injury or death.

Warning

The equipment you will be using to compress Air or Nitrox will expose you to both low and high-pressure gas. Gas, even under moderate pressures, can cause extreme bodily harm. Never allow any gas stream to be directed at any part of your body.

Warning

Any pressurized hose can cause extreme harm if it comes loose or separates from its restraint (or termination) while under pressure and strikes any part of your body. Use appropriate care in making and handling all gas connections.

Warning

Do not use any form of mineral oil or synthetic lubricant not rated for the compressor in this system. Use only the recommended Compressor Lubricant. Never mix the Compressor Lubricant with other lubricants. The use of improper lubricants can lead to fire or explosions, which may cause serious personal injury or death.


3.0 Safety And Operation Precautions

Because a compressor is a piece of machinery with moving and rotating parts, the same precautions should be observed as with any piece of machinery of this type where carelessness in operations or maintenance is hazardous to personnel. In addition to the many obvious safety precautions, those listed below must also be observed:

- 1) Read all instructions completely before operating any compressor or Nitrox System.
- 2) For installation, follow all local electrical and safety codes, as well as the National Electrical Code (NEC) and the Occupational Safety and Health Administration (OSHA) standards.
- 3) Electric motors must be securely and adequately grounded. This can be accomplished by wiring with a grounded, metal-clad raceway system to the compressor starter; by using a separate ground wire connected to the bare metal of the motor frame; or other suitable means.
- 4) Protect all power cables from coming in contact with sharp objects. Do not kink power cables and never allow the cables to come in contact with oil, grease, hot surfaces, or chemicals.
- 5) Make certain that power source conforms to the requirements of your equipment.
- 6) Pull main electrical disconnect switch and disconnect any separate control lines, if used, before attempting to work or perform maintenance. "Tag Out" or "Lock Out" all power sources.
- 7) Do not attempt to remove any parts without first relieving the entire system of pressure.
- 8) Do not attempt to service any part while System is in an operational mode.
- 9) Do not operate the System at pressures in excess of its rating.
- 10) Do not operate compressor at speeds in excess of its rating.
- 11) Periodically check all safety devices for proper operation. Do not change pressure setting or restrict operation in any way.
- 12) Be sure no tools, rags or loose parts are left on the Compressor System.
- 13) Do not use flammable solvents for cleaning the Air Inlet Filters or elements and other parts.
- 14) Exercise cleanliness during maintenance and when making repairs. Keep dirt away from parts by covering parts and exposed openings with clean cloth or Kraft paper.
- 15) Do not operate the compressor without guards, shields, and screens in place.
- 16) Do not install a shut-off valve in the compressor discharge line, unless a pressure relief valve, of proper design and size, is installed in the line between the compressor unit and shut-off valve.
- 17) Do not operate in areas where there is a possibility of inhaling carbon monoxide, carbon dioxide, nitrogen, or flammable or toxic fumes.
- 18) Be careful when touching the exterior of a recently run electric, gasoline, or diesel motor - it may be hot enough to be painful or cause injury. With modern motors this condition is normal if operated at rated load - modern motors are built to operate at higher temperatures.
- 19) Inspect unit daily to observe and correct any unsafe operating conditions found.
- 20) Do not "play around" with compressed air, or direct air stream at body, as this can cause injuries.
- 21) Compressed air from this machine absolutely must not be used for food processing or breathing air without adequate downstream filters, purifiers and controls and periodic air quality testing.
- 22) Always use an air pressure-regulating device at the point of use, and do not use air pressure greater than marked maximum pressure.
- 23) Check hoses for weak or worn conditions before each use and make certain that all connections are secure.

The user of any compressor or Nitrox System manufactured by Nuvair is hereby warned that failure to follow the preceding Safety and Operation Precautions can result in injuries or equipment damage. However, Nuvair does not state as fact or does not mean to imply that the preceding list of Safety and Operation Precautions is all-inclusive, and further that the observance of this list will prevent all injuries or equipment damage.

4.0 Description of the Compressor



5.0 System Components

Coltri MCH30/MCH22-36 High Pressure Air Compressor

4 Cylinder, 4 stage, Air Cooled

Hour Meter

Electric Motor: 220V/230V or 440V/460V, 3 Phase, 50 or 60 Hz

MCH22 10 hp (7.5 kW), MCH22 15 hp (11 kW), MCH22 20 hp (15 kW)

NEMA 4 box

Interstate Pressure Gauges

3 Condensate Separators

Large Stainless Steel Interstage Cooling Tubes

Low Pressure Oil Pump with Filter

Oil Level Sight Gauge and Oil Pressure Gauge

Automatic Condensate Drains

Load less Start

Low Oil Shutdown Switch

High Temp Switch

Lubricant:

Nuvair 455 Food Grade Lubricant (standard)

Nuvair 751 Diester Based Lubricant (optional)

Aluminum Frame with isolation vibration mounts

6.0 Compressor Specifications

	MCH 22	MCH 30	MCH 36
Charging Rate Filling an 80 cu ft tank from 500 psi	15.8 SCFM (447 L/min)	20.4 SCFM (577 L/min)	27 SCFM (764 L/min)
FAD	13.2 CFM (374 L/min)	17 CFM (481 L/min)	22.5 CFM (637 L/min)
Electrical Power Requirements			
208-220 V / E1 / 60 Hz	46 Amps 10 hp (7.4 kW)	N/A	N/A
208-230 V / E3 / 60 Hz	30 Amps 10 hp (7.4 kW)	45 Amp 15 hp (11KW)	60 Amp 20 hp (15KW)
380-415 V / E3 / 50 Hz	17 Amps 10 hp (7.4 kW)	25 Amp 15 hp (11KW)	33 Amp 20 hp (15KW)
440-480 V / E3 / 60 Hz	15 Amps 10 hp (7.4 kW)	21 Amp 15 hp (11KW)	29 Amp 20 hp (15KW)
Max Operating Pressure	Up To 6000 psi (414 bar)		
Pumping Unit RPM	880	1100	1300
Number of Stages	4	4	4
Lubrication	Pressure Lubrication, capacity 4 L		
Oil Pressure	58 psi, 4 bars 21.75 psi, 1.5 bars 14.5 psi, 1 bar	cold routine use minimum pressure	
Air Quality	Grade E		

 **Caution**

Ambient room temperature should never exceed 113°F (45°C) during operation of the Compressor System. Operation at higher temperatures may lead to system damage and malfunction.

6.1 Unpack and Installation


- 1) Please read all information supplied before physically installing the Compressor System.
- 2) Unpack the system and remove from the pallet. Visually inspect the system to make sure there has been no damage during shipping. If damaged, please call Nuvair to file a damage report. Please take photos and supply detailed information about the damage.
- 3) Place the system in a permanent location allowing a minimum spacing of 36" from adjacent walls. Select a location where ambient room temperature is a minimum of +41°F to a maximum +113°F (°C Min. +5° - Max. +45°).
- 4) Make sure the installation space is well ventilated.

6.2 Electrical Connection

- Please read all information supplied before Connecting Electricity to the Compressor System.
- You should hire a licensed electrician to install any electric compressors purchased from Nuvair.
- The compressor is delivered with raw leads ready to be installed into a junction box.
- In the event a plug is needed, Nuvair recommends that the licensed electrician doing the install determines the plug necessary.
- Make sure your electrician follows approved and compliant standards for your location.

7.0 Checks to be run at the start of each working day

Inspect the exterior of the compressor (couplings, pipes, pneumatic components etc.) and check for any oil leaks. Replace parts where necessary or contact **Nuvair**.



7.1 Lubricating oil level check

Check that the level of lubricating oil (**a**) is within acceptable limits (i.e. between min. and max.). Note that an excessive quantity of oil can leave deposits on the valves while too low a level prevents proper lubrication and could cause engine seizure. If the oil level is not within the minimum and maximum limits top up or drain as described in section 11.8 Changing the lubricating oil and filter”.

7.2 Check that the refill hoses are in good condition

Inspect the refill hoses and make sure there are no cuts, holes, abrasions, leaks etc. If necessary replace with new hoses.

7.3 Storing technical documentation

The use and maintenance manual and its appendices must be stored carefully and must always be kept where they can be accessed easily for immediate review.

Warning

This User Manual contains important safety information and should always be available to those personnel operating this equipment. Read, understand, and retain all instructions before operating this equipment to prevent injury or equipment damage.

8.0 Gauge Panel



1st stage pressure gauge (1)

The (1) gauge indicates the pressure inside the 1st compression stage. If the Pressure is not between 45 psi (3 bar) and 60 psi (4 bar) switch off the compressor and contact Nuvair.

2nd stage pressure gauge (2)

The (2) gauge indicates the pressure inside the 2nd compression stage. If the Pressure is not between 230 psi (16 bar) and 290 psi (20 bar) switch off the compressor and contact Nuvair.

3rd stage pressure gauge (3)

The (3) gauge indicates the pressure inside the 3rd compression stage. If the Pressure is not between 940 psi (65 bar) and 1200 psi (80 bar) switch off the compressor and contact Nuvair.

4th stage pressure gauge / Working Pressure Gauge (4)

This (4) gauge indicates the pressure as it exits the compressor. If the Pressure fails to reach the pressure set on the pressure switch, switch off the compressor and contact Nuvair.

Fill Pressure Gauge

Pressure at the fill whips.

Oil

Pressure

Gauge

If No Oil Pressure or High Pressure readings occur, switch off compressor and contact Nuvair.

Oil Pressure	58 psi (4 Bar)	Cold Routine Use Minimum Pressure
	21.75 psi (1.5 Bar)	
	14.5 psi (1 Bar)	

9.0 Overpressure Safety Valves

Each stage of the compressor is equipped with an overpressure relief valve to ensure that the unit will not be damaged in the event that the pressure shutoff switch fails to work. The final stage valve is pre-adjusted to 3200 psi (225 bar), 4300psi (300bar), 4700psi (330bar) or 6000 psi (425 bar) dependent on the final pressure specified when the unit was ordered.


⚠ Caution

Tampering with the safety valve to increase the pressure setting is strictly forbidden. Tampering with the safety valve can seriously damage the compressor, cause serious injury to personnel and renders the warranty null and void.

10.0 Bottle Refill

To refill the bottles proceed as follows:

- Fit the hose connector (a) to the tank valve (b)
- Screw in the fixing knob (c) until it is completely tightened
- Check that the bleed valve (f) is closed by rotating it clockwise
- Open the valve (d) by rotating it counter clockwise
- Open the valve (e) by rotating it counter clockwise
- Start the compressor with the on off switch
- When the refill has been completed the compressor shuts down automatically
- Close valves (d) and (e) by rotating them clockwise
- Open the bleed valve (f) by rotating it counter clockwise until all the residual air in the fitting has been expelled
- Unscrew the fixing knob (c) by rotating it counter clockwise
- Disconnect the bottle coupling.



Options for this compressor that may or may not be installed are:

- Pressure Switch: Shuts down the compressor at a set pressure
- Dial-A-Pressure Switch: Allows the operator to dial in a pressure for the compressor to automatically shut off at when the pressure is reached during the filling process.

Notice

During refill the operator must be in the work area. It is advisable, during the bottle refill phase, to submerge the bottles in cold water so as to reduce the drop in pressure that accompanies cooling of the bottle.

Warning

During bottle refill those not involved in the refill procedure must maintain a safety distance of at least 9 feet (3 meters). Also, it is forbidden to disconnect the hoses from the fittings or the refill tap while the machine is under pressure.

Danger

Should bottles show evident signs of internal or external corrosion, do not refill them even if they have been tested.

Warning

Use only tested bottles (as proven by a test stamp and/or certificate). The working and bottle refill pressures are shown on the bottles themselves. It is forbidden to refill them at a pressure greater than that indicated.

11.0 Maintenance

11.1 Foreword

To obtain the best possible performance from the compressor and ensure a long working life for all its parts it is essential that personnel follow the use and maintenance instructions with extreme diligence. It is thus advisable to read the information below and consult the manual every time an inconvenience arises. For further information please contact Nuvair:

11.2 General

- Proper preservation of the compressor requires thorough cleaning.
- This type of refill station, designed and built according to the most advanced technological criteria, requires only minimum preventive and routine maintenance.
- Before carrying out any maintenance tasks, run checks and/or controls on the compressor, switch off the compressor, remove the plug from the mains socket.
- The residual pressure present in the compressor and all lines must be released.
- During disassembly and re-assembly of the compressor, always use suitable wrenches/tools so as not to damage the relevant components.
- Loosen stiff parts with a copper or plastic mallet.
- When refitting parts make sure they are clean and lubricated sufficiently.
- Compressor maintenance tasks must only be carried out by authorized personnel and recorded on page 31 Maintenance Log of this manual.

11.3 Unscheduled Work

Involves repairs and/or replacement of the mechanical parts of one or more compressor components, this work normally needs to be done after some years of use. If substantial modifications are made, the manufacturer cannot be held liable for any dangers that might arise. This work must be carried out by a Nuvair qualified mechanic.

11.4 Scheduled Maintenance Table

Maintenance	Every 5 hours	Every Day	Every Year	250 (hours)	500 (hours)	1000 (hours)	3000 (hours)
Lubricating Oil Check		○					
Automatic Shutdown Check		○					
Condensate Container discharge	○	○					
Belt wear and tension			○		●		
Air intake filter			●	●			
Fitting / hose leak check			○		○		
Oil Filter and Oil change			●	●*			
Separator filter element cleaning			○			○	
1 st – 2 nd – 3 rd stage Valve replacement					○	●	
4 th stage valve replacement					●		
Water & HP oil separator replacement							●
HP filter body replacement							●

○ Checking and cleaning ● Change

*Oil Change every 100 hours when used with Nitrox

11.5 Troubleshooting

Problem	Cause	Solution
-The electric motor does not start	<ul style="list-style-type: none"> •Phase missing 	<ul style="list-style-type: none"> •Check fuses or capacitor
-Rotation speed and flow rate decrease	<ul style="list-style-type: none"> •Motor power too low •The belt slips 	<ul style="list-style-type: none"> •Check the motor and the line •Restore drive belt tension
-The flow rate diminishes without rpm decreasing	<ul style="list-style-type: none"> •Valves not working •4th stage piston worn •Fittings loose / leaking seals •Intake filter clogged •Intake extension kinked •Piston or piston rings worn 	<ul style="list-style-type: none"> •Contact technical support •Contact technical support •Check for leaks with soapy water and eliminate them •Replace filter •Straighten, use stiffer pipe •Contact technical support
-Air smells of oil	<ul style="list-style-type: none"> •Cartridge filter exhausted •Piston rings worn •Condensate not being drained 	<ul style="list-style-type: none"> •Replace filter •Contact technical assistance •Check Auto Drains & manually drain more often
-Compressor overheats	<ul style="list-style-type: none"> •Direction of rotation wrong •Cooling tubes dirty •Incomplete valve closure (causing overload of another stage) •Poor Ventilation 	<ul style="list-style-type: none"> •Check direction of rotation •Clean Cooling Tubes •Contact technical support •Contact technical support

11.6 Checking and changing the lubricating oil and filter

During the compressors initial break-in period the original oil filter and lubricating oil must be changed at the 25 hour mark. After the initial change of lubricants and filter the oil and oil filter must be changed every 100 hours of use or annually, whichever comes first.

HP Compressor Lubricant: Only use lubricants rated for use with Nitrox, such as Nuvair 455 Synthetic Food Grade Lubricant or Nuvair 751. **Never mix Compressor Lubricants.** Nuvair Compressors are shipped with Nuvair 455 Synthetic Food Grade Lubricant or Nuvair 751 in the compressor. Coltri OIL CE750 and Anderol 755 may also be used, but not mixed with Nuvair oil.

 **Warning**

Use only the specified Nuvair Lubricants in this system. The use of incompatible lubricants presents a risk of fire and/or explosion, and may result in system damage. This can lead to severe personal injury and death.

 **Danger**

Do not carry out these tasks if the compressor has only just shut down; wait for the compressor to cool. Pressure must be drained before opening LP Fill Plug.

Any oil spilt during the oil/filter change could cause personnel to slip; wear protective garments and anti-slip footwear and remove traces of oil immediately.

Both oil and filter are classified as special wastes and must therefore be disposed of in compliance with the anti-pollution laws in force.

All maintenance work must be carried out with the compressor OFF and the power supply lead unplugged from the main socket.

11.7 Checking the Oil Level

⚠ Notice


The compressor must be placed on a solid surface with a tilt of no more than 5°.

The oil level must be checked every 5 working hours of the compressor.
 The oil level must be between the minimum and the maximum shown on the oil level indicator.
 (See close-up picture bottom of next page)
 If the oil level is above the maximum level:

- Position a recipient under the drain hose so that the oil flows into the exhausted oil recipient.
- Open the drain valve and let the oil flow out until the oil level returns within the max. and min. limits
- Close the drain valve.

If the oil level is below the minimum level:

- Open the top fill plug
- Top off with oil until the level returns within the max. and min. limits
- Close the fill plug.



⚠ Caution

After running the compressor, the lubricant will be very hot. Take care when removing the drain plug and draining the lubricant to avoid burns.

⚠ Notice

Recommended Nitrox Compressor Lubricant is changed when the first 25 hours of use is reached, then change lubricant in 100 hour cycles or annually.

⚠ Caution

Wear gloves when handling compressor lubricant. If contact with skin is made, wash the skin surface with soap and water.

⚠ Caution

Always wear goggles when handling compressor lubricant. These materials can cause eye irritation. If you accidentally get lubricant into your eyes, flush with fresh water for 15 minutes and contact a physician if irritation develops.




⚠ Caution

Compressor lubricant should be incinerated after use in a licensed facility in accordance with Federal, State, and local regulations.

11.8 Changing the lubricating oil and filter

The lubricating oil must be changed every 250 working hours or annually. Every time the lubricating oil is changed the oil filter must be changed too.

- Position a recipient under the drain so that the oil flows into the exhausted oil recipient (recipient capacity of at least 1.2 gallons or 5 liters required).
- Open the oil fill plug (A).
- Open the hose (B) and let all the oil flow out.
- Replace the filter (C) with a new one PN SC000688.
- Close the drain hose (B).
- Fill the oil sump with 1 gallon or 3.5 liters of oil from top oil plug
- Close the oil fill plug (A).
- Switch on the compressor and run it depressurized for 30 seconds.
- Switch off the compressor and remove the plug from the mains socket.
- Check the oil level (D); if it is not between the min. and max. lines proceed with the tasks described in paragraph 11.7.




11.9 Tightening Torque Values – Should be done at 25 hour maintenance

The table below shows tightening torques for bolts or hexagonal-head screws or socket screws lubricated with grease, except for specific cases indicated in the manual.

Pipe connections (swivel nuts, compression fittings) should be finger tight, PLUS an additional 1/2 turn.


Tightening Torque Values	
Thread	Maximum Torque
M6 - 1/4"	10Nm (7ft-lbs)
M8 - 5/16"	25Nm (18ft-lbs)
M10 - 3/8"	45Nm (32ft-lbs)
M12 - 1/2"	75Nm (53ft-lbs)
M14 - 9/16"	120Nm (85ft-lbs)
M16 - 5/8"	200Nm (141ft-lbs)

6 bolt and 4 bolt torque sequence



11.10 Changing the Air intake filter

After putting the compressor into service the intake filter must be changed after the first 50 working hours. The air filter must then be changed every 250 working hours or annually. Every 50 working hours rotate the filtration cartridge inside the filter 90°.



The air intake filter must be changed every 250 working hours or annually. If the compressor is used in a dusty environment the filter change interval should be reduced to every 100 hours.

Change the Air filter as follows:

- unhinge the air filter cover by flipping lever**
- remove the air filter cartridge**
- replace the cartridge with a new one**
- close the cover**



Do not carry out these tasks if the compressor has just shut down and is hot; wait for the compressor to cool down. All maintenance work must be carried out with the compressor OFF and the power supply lead unplugged from the wall socket.

Notice


If the compressor is used in a dusty environment the filter change interval should be reduced to every 100 hours.

12.0 Transmission Belt

Belt tension must be checked monthly. The transmission belts must be replaced every 500 working hours of the compressor.

12.1 Checking the Transmission Belt

To check for proper transmission belt tension (a) exert a pressure of approximately 22lbs. (10 Kg) on the belts; check that the belts do not flex by more than 1 cm with respect to their original position. Should they flex more than this the belts must be replaced.



13.0 HP Compressor Filtration Active Carbon Filters / Molecular Sieve

The HP Compressor comes standard with Triplex filtration, utilizing a single Filter Element. Do **NOT** use any substitute. Change filter elements every 60,000 cubic feet of air pumped. If the compressor system is operated in high humidity and/or high temperature, filter elements must be changed more often. See 13.1 for details on filter element life factors.

- 1) Shut down the Compressor System
- 2) Open Manual Bleed Drain Valve on filter towers to drain pressure. Leave valve open.
- 3) Unscrew the Filter Canister Cap.
- 4) Remove expended Element from Filter Canister.
- 5) Install New Element place pressure on element to seat the element.
- 6) Reinstall Cap to Canister.
- 7) Close Manual Condensate Valve.



HP Filter Replacement parts:
X65677
X65247

3



4



5



Warning

Be sure that all pressure has been relieved from the system prior to opening any filtration canister. Failure to vent pressure from the system prior to opening the canister can lead to serious personal injury or death. Difficulty turning the filter cap may indicate there still is pressure in the filter canister.

⚠ Caution

If the compressor is located in an area where there is high humidity and high heat, the life of all Filtration Elements may be as little as 35% of rated operating capacity. Check the Compressor manual and Appendix for details on Filter Element Life Factors.

13.1 Temperature Affect on Filter Life

Filter replacement frequency calculation table				
Temperature (°F)	Temperature (°C)	Filter duration (hours)	Filter duration (hours)	Filter duration (hours)
		MCH22	MCH30	MCH36
104	40	33	25	21
86	30	56	42	35
68	20	88	65	54
50	10	132	98	81
32	0	244	180	150
23	-5	388	287	238

⚠ Warning

The active carbon filters are classified as special waste once the compressor has been used to make air: they must be disposed of in compliance with the anti-pollution standards in force.

⚠ Notice

The Condensate tank must be drained at the end of every working day or every 2 to 3 hours of operation. The Compressor Condensate must be drained every 5-10 minutes of operation.


13.2 Condensate Discharge

An outflow of condensate water with lubricating oil is normal during refills: the quantity will depend on the level of humidity in the air. The condensate must be disposed of as per your local "Waste disposal" rules.

To Drain the Condensate Tank Open the Manual bleed valve pictured right and drain into a portable container for disposal.

The Condensate Tank must be drained daily or every 6 working hours. You may run a hose from the condensate tank into a Larger receiver and leave the ball valve in the open position.

- Manually Open Auto Drain Valves each day to check for Condensate and that the Auto Drains are functioning properly.



14.0 Power Requirements

Warning

Never use extension cords to provide power to your Compressor System. The system must be properly wired according to national and local electrical codes by a qualified electrician. Improper wiring may lead to fires, which can cause serious personal injury or death.

Electrical wiring and connections should be made by a qualified electrician in accordance with all national and local electrical codes. Check all System Specifications provided in this manual when working on the Compressor System the main breaker at the power source must be “locked out” in the Off position.

14.1 Amperage Load for System

208-220 V / E1 / 60 Hz	46 Amps 10 hp (7.4 kW)	N/A	N/A
208-230 V / E3 / 60 Hz	30 Amps 10 hp (7.4 kW)	45 Amp 15 hp (11KW)	60 Amp 20 hp (15KW)
380-415 V / E3 / 50 Hz	17 Amps 10 hp (7.4 kW)	25 Amp 15 hp (11KW)	33 Amp 20 hp (15KW)
440-480 V / E3 / 60 Hz	15 Amps 10 hp (7.4 kW)	21 Amp 15 hp (11KW)	29 Amp 20 hp (15KW)

14.2 Rotation Check

Always turn on (bump) starter and run motor very briefly to check for proper direction of rotation.
 (See arrow on electric motor and flywheel belt guard)

Notice

Operation in reverse direction for extended periods of time will cause a Reciprocating Compressor to run hot and perform poorly and may cause permanent damage.



15.0 Storage

Should the compressor not be used, it must be stored in a dry sheltered area at an ambient temperature of between 32°F and 104°F (0 °C and 40 °C). Store the compressor away from sources of heat, flames or explosive.

15.1 Stopping the machine for a brief period

If you do not intend to use the compressor for a brief period proceed with general cleaning. Once the compressor has cooled down you should wipe off dirt, dust and moisture on the compressor and the surrounding area.

15.2 Stopping the machine for a long period

If you do not intend to use the compressor for a long period, extract the active carbon filter cartridge. Run the compressor for a few minutes without actually filling bottles so as to flush out all the residual condensate. Stop the compressor, disassemble the intake filter, restart the compressor and spray a few drops of oil into the air intake hole so that a light film of lubricant is aspirated and penetrates the interior of the compressor. Stop the compressor and refit the air intake filter. Clean the external parts: eliminate any moisture, salt or oil deposits. Protect the compressor from dust and water by storing it in a clean, dry place. Switch off the machine via the main switch and remove the plug from the mains power socket. Proceed with a thorough general clean of all machine parts. During machine downtimes it is advisable to run the compressor for 20 minutes every 15 days.

16.0 Dismantling and Putting the Compressor Out Of Service

Should you decide not to use the compressor or any of its parts any longer you must precede with its dismantling and putting it out of service. These tasks must be carried out in compliance with the standards in force.

Warning

Should the compressor, or a part of it, be out of service its parts must be rendered harmless so they do not cause any danger.

Warning

Bear in mind that oil, filters or any other compressor part subject to differentiated waste collection must be disposed of in compliance with the standards in force.

16.1 Waste Disposal

Use of the compressor generates **waste** that is classified as **special**. Bear in mind that residues from industrial, agricultural, crafts, commercial and service activities not classified by quality or quantity as urban waste must be treated as special waste. Deteriorated or obsolete machines are also classified as special waste. Special attention must be paid to active carbon filters as they cannot be included in urban waste: observe the waste disposal laws in force where the compressor is used. Bear in mind that it is compulsory to record loading/unloading of exhausted oils, special wastes and toxic-harmful wastes that derive from heavy/light industry processes. Exhausted oils, special wastes and toxic-harmful waste must be collected by authorized companies. It is especially important that exhausted oils be disposed of in compliance with the laws in the country of use.

Notice

Disassembly and demolition must only be carried out by qualified personnel.

16.2 Dismantling the compressor

Dismantle the compressor in accordance with all the precautions imposed by the laws in force in the country of use. Before demolishing request an inspection by the relevant authorities and relative report. Disconnect the compressor from the electrical system. Eliminate any interfaces the compressor may have with other machines, making sure that interfaces between remaining machines are unaffected. Empty the tank containing the lubricating oil and store in compliance with the laws in force. Proceed with disassembly of the individual compressor components and group them together according to the materials they are made of: the compressor mainly consists of steel, stainless steel, cast iron, aluminum and plastic parts. Then scrap the machine in compliance with the laws in force in the country of use.

Notice

At every stage of demolition observe the safety regulations contained in this manual carefully.

17.0 Instructions for Emergency Situations

17.1 Fire

In the event of fire use a CO₂ extinguisher in compliance with the relevant standards in force. Contact the fire department.

18.0 Maintenance Register

18.1 Customer Service

Customers continue to receive assistance after the purchase of a compressor. To this end **Nuvair** has created a customer service network covering the entire country.

Notice

Our qualified technicians are at your disposal at any time to carry out maintenance work or repairs; we use only original spare parts so as to ensure quality and reliability.

18.2 Scheduled Maintenance

The scheduled maintenance program is designed to keep your compressor in perfect working order. Some simple tasks, described in this manual, can be carried out directly by the customer; others, instead, require that the work be carried out by trained personnel. For the latter we recommend you always contact our office. This section provides a simple tool with which to request assistance and register completed scheduled maintenance work. Start-up and maintenance checks/tasks, once completed by our qualified technician, are registered in this maintenance chapter by way of an official stamp, signature and inspection date; the number of working hours is also registered. The maintenance schedules/coupons easily let you know when our assistance service should be contacted to carry out work.

18.3 Using the compressor under heavy duty conditions

Where compressors are used in particularly difficult conditions (high levels of pollution,

Nuvair MCH36 Open Vertical

presence of solid particulate in suspension etc.), scheduled maintenance tasks must be carried out more frequently as per the advice given by our assistance network.

18.4 Nuvair Customer Care Contact

Telephone: +1 805 815 4044
Fax: +1 805 486 0900
e-mail: info@Nuvair.com
web: www.Nuvair.com/manuals.html

19.0 Spare Parts List

HP Air Compressor parts list.

Compressor System Components	Type	Part Number
Compressor Lubricant, Food Grade, Nitrox Compatible	Nuvair 451, 1 Gal (Other Sizes Available)	9406
	Nuvair 751, 1 Gal (Other Sizes Available)	9403
HP Filter Elements		
Black Canisters	Absorbent Filter	X65677
	Triplex Filter	X65247
Blue Canisters	Absorbent Filter	SC000543-M
	Triplex Filter	SC000543-MHC
Air Intake Filter Element		36-05-0504
CO ₂ Moisture Sensor Element		592-6
Oil Filter	Pre 2018 Element	MCH 36-06-007
Oil Filter	Spin on	SC000688

21.0 Appendix

Supply and Breathing Air Specifications

All supply and breathing air must meet the following requirements of CGA G-7.1-1997. Supply air delivered to the Membrane System must be purified to meet Grade D or E quality, and periodic air quality testing to assure compliance is recommended. All breathing air for diving produced by the downstream compressor must be purified to meet Grade E quality, and periodic air quality testing to assure compliance is mandatory.

Item	Grade D	Grade E
Oxygen	19.5-23.5%	20-22%
Carbon Dioxide (maximum)	1000 PPM	1000 PPM
Carbon Monoxide (maximum)	10 PPM	10 PPM
Hydrocarbons (maximum)	Not specified	25 PPM
Water Vapor (maximum)	Not specified	Not specified
Dew Point (maximum) (1)	Not specified	Not specified
Oil & Particles (maximum) (2)	5 mg/m3	5 mg/m3
Odor	None	None

Notes: (1) Dew Point of supply air must be >10°F (6°C) colder than coldest ambient air expected
 (2) Supply air delivered to the Membrane System must contain <0.003 PPM Oil Vapor

All breathing Nitrox produced for diving must be purified to meet these same requirements, except for oxygen content. Nitrox oxygen content must measure within +/- 1% O₂ of the specified value of the mixture using a properly calibrated Oxygen Analyzer (i.e. Nitrox produced with a target content of 32% O₂ must measure in the range of 31-33% O₂). Periodic air quality testing to assure compliance is mandatory.

Filter Element Life Factors

Breathing air filter element life is typically rated by manufacturer based on an air temperature of 80°F at the filter inlet. Under normal operation this temperature is 12°F (5°C) warmer than the ambient air, resulting in an equivalent ambient temperature rating at 68°F (20°C).

To determine element life at a different ambient temperature, multiply the rated life by the life factor listed below:

Filter Temperature	Ambient Temperature	Filter Element Life Factor
53°F (12°C)	41°F (5°C)	2.6 x Life
62°F (17°C)	50°F (10°C)	1.8 x Life
71°F (23°C)	59°F (16°C)	1.35 x Life
80°F (27°C)	68°F (20°C)	1 x Life
89°F (32°C)	77°F (25°C)	0.8 x Life
96°F (36°C)	84°F (29°C)	0.55 x Life
105°F (41°C)	93°F (34°C)	0.45 x Life
114°F (46°C)	102°F (39°C)	0.35 x Life

Nuvair COMPRESSOR SYSTEM WARRANTY

Nuvair extends a limited warranty, which warrants the Compressor System to be free from defects in materials and workmanship under normal use and service for a limited period. All other Original Equipment Manufacturer (OEM) components used in the system are warranted only to the extent of the OEM's warranty to Nuvair. Nuvair makes no warranty with respect to these OEM components, and only warrants the workmanship that Nuvair has employed in the installation or use of any OEM component. This warranty is not transferable.

Nuvair will, at its discretion and according to the terms as set forth within, replace or repair any materials which fail under normal use and service and do not exhibit any signs of improper maintenance, misuse, accident, alteration, weather damage, tampering, or use for any other than the intended purpose. Determination of failure is the responsibility of Nuvair, which will work together with the customer to adequately address warranty issues. When any materials are repaired or replaced during the warranty period, they are warranted only for the remainder of the original warranty period. This warranty shall be void and Nuvair shall have no responsibility to repair or replace damaged materials resulting directly or indirectly from the use of repair or replacement parts not approved by Nuvair.

Maintenance Items:

Any materials which are consumed, or otherwise rendered not warrantable due to processes applied to them, are considered expendable and are not covered under the terms of this policy. This includes maintenance and consumable items listed as part of a suggested maintenance program included with system documentation.

Return Policy:

Application for warranty service can be made by contacting Nuvair during regular business hours and requesting a Return Material Authorization number. Materials that are found to be defective must be shipped, freight pre-paid, to the Nuvair office in Oxnard, California. Upon inspection and determination of failure, Nuvair shall exercise its options under the terms of this policy. Warranty serviced materials will be returned to the customer via Nuvair's preferred shipping method, at Nuvair's expense. Any expedited return shipping arrangements to be made at customer's expense must be specified in advance.

Limitation of Warranty and Liability:

Repair, replacement or refund in the manner and within the time provided shall constitute Nuvair's sole liability and the Purchaser's exclusive remedy resulting from any nonconformity or defect. Nuvair shall not in any event be liable for any damages, whether based on contract, warranty, negligence, strict liability or otherwise, including without limitation any consequential, incidental or special damages, arising with respect to the equipment or its failure to operate, even if Nuvair has been advised of the possibility thereof. Nuvair makes no other warranty or representation of any kind, except that of title, and all other warranties, express or implied, including warranties of merchantability and fitness for a particular purpose, are hereby expressly disclaimed. No salesman or other representative of Nuvair has authority to make any warranties.

Nuvair MCH36 Open Vertical
Additional Record of Changes

It is the responsibility of the owner of this product to register their ownership with Nuvair by sending the warranty card provided to Nuvair. This card is to establish registration for any necessary warranty work and as a means of communication that allows Nuvair to contact the user regarding this product.

The user must notify Nuvair of any change of address by the user or sale of the product. All changes or revisions to this manual must be recorded in this document to ensure that the manual is up to date.

Change Date	Description of Change
04/30/14	Updated pictures and information throughout manual
03/20/20	Updated images, part numbers and specifications

Notes:



Nuvair
Phone +1805 815 4044
Fax +1 805 486 0900
1600 Beacon Place
Oxnard, CA 93033 USA
info@Nuvair.com
www.Nuvair.com
Rev.03.20