

**Connect incoming  
gas to corresponding  
connection**

**Connect correct  
fill whip for  
application**



**Turn on gauge**

**Connect to  
LP air supply  
150psi max**

**Increase flow control valve  
to no more than one beat per second**